



NOTES

1. REMOVE EXCESS SOIL TO EXPOSE ROOT FLARE AND TO ENSURE TOP MOST ROOT IS NO MORE THAN 1-INCH BELOW ROOT BALL SURFACE. SEVER CIRCLING ROOTS WHERE APPROPRIATE. SET TOPMOST ROOT 2 INCHES ABOVE ADJACENT FINISHED GRADE. TRUNK FLARE SHALL BE VISIBLE.
2. CUT AND REMOVE WIRE BASKETS FROM SIDES OF ROOT BALL WITHOUT DEFORMING BALL. CUT OFF AND REMOVE BURLAP AND ROPE FROM TOP HALF OF ROOT BALL. COMPLETELY REMOVE SYNTHETIC ROPE AND NON-BIODEGRADABLE BURLAP.

DRAWN JRF		
ENGR. NJK		
REV.	DATE	APPR.

City of Oregon City
 Public Works Standard Drawings
STREET TREE PLANTING
IN PLANTER STRIP

SCALE	N.T.S.
DATE	APRIL 2012
APPR.	NJK
DWG. NO.	530